

Gorden Module Cover Installation

Notching Instructions for Case-IH Modules

Installation of Gorden module covers on some Case-IH manufactured modules require a notch cutout as shown below.

Hold supplied template against side frame of module and mark the cutout profile both on the left and right sides of the module's first cross bar. This notch is required on the front left and right modules and the front side of the second left and right modules. Total of six notches must be cutout. A cutting torch and grinder are the tools suggested for this modification.

